




PARTS LIST

for the

Kodak X-Omat 480 RA PROCESSOR



H108_0318BA

PLEASE NOTE

The information contained herein is based on the experience and knowledge relating to the subject matter gained by Eastman Kodak Company prior to publication.

No patent license is granted by this information.

Eastman Kodak Company reserves the right to change this information without notice, and makes no warranty, express or implied, with respect to this information. Kodak shall not be liable for any loss or damage, including consequential or special damages, resulting from the use of this information, even if loss or damage is caused by Kodak's negligence or other fault.

CAUTION



This equipment includes parts and assemblies sensitive to damage from electrostatic discharge. Use caution to prevent damage during all service procedures.


Table of Contents

Description	Page
Locators	1-1
Covers and Panels	2-1
Top Cover and Panels	2-3
Side Panels (Old Style)	2-4
Feed End Panels	2-5
Feed Tray	2-6
Splash Guards	2-7
Recirculation Pump Guard and Dryer Blower Motor Cover	2-8
Roller Transport System	3-1
Rack Positions	3-3
Basic Roller Assembly	3-6
Detector Crossover Assembly	3-7
Detector Crossover - Drive Side	3-9
Detector Crossover - Non-Drive Side	3-11
Developer Rack Assembly	3-13
Developer Rack - Top Exit Rollers	3-15
Developer Rack - Other Rollers	3-17
Developer Rack - Turnaround Rollers	3-19
Developer/Fixer Crossover Assembly	3-21
Developer/Fixer Crossover - Drive Side	3-23
Developer/Fixer Crossover - Non-Drive Side	3-25
Fixer Rack Assembly	3-27
Fixer Rack - Top Exit Rollers	3-29
Fixer Rack - Other Rollers	3-31
Fixer Rack - Turnaround Rollers	3-33
Fixer/Wash Crossover Assembly	3-35
Fixer/Wash Crossover - Drive Side	3-37
Fixer/Wash Crossover - Non-Drive Side	3-39
Wash Rack Assembly	3-41
Wash Rack - Squeegee Rollers	3-43
Wash Rack - Other Rollers	3-45
Wash Rack - Turnaround Rollers	3-47


Description	Page
Squeegee Assembly	3-49
Squeegee Assembly - Drive Side	3-51
Squeegee Assembly - Non-Drive Side.....	3-53
Main Drive Assembly	4-1
Main Drive Assembly	4-3
Rack Support Bar	4-8
Dryer Assembly	5-1
Dryer Assembly	5-3
Dryer Rollers and Air Tubes.....	5-5
Heater Parts.....	5-9
Blower and Motor Assembly.....	5-11
Lower Dryer Adjustment Assembly	5-12
Plumbing	6-1
Developer Circulation Plumbing Diagram	6-3
Fixer Circulation Plumbing Diagram.....	6-5
Washer Circulation Plumbing Diagram	6-7
Developer/Fix Thermowell Assemblies	6-9
Filter Canister Assembly.....	6-11
Recirculation Pump Assembly.....	6-13
Replenishment Control Assembly	6-15
Developer/Fixer Replenishment Pumps	6-17
Drain Assembly.....	6-19
Developer Heat Exchanger	6-21
Electrical	7-1
Transformer Box	7-3
Front Door and Internal Panel.....	7-5
500 Circuit Board Assembly	7-7
Electrical Box	7-9
Control Panel	7-11
Control Panel/Display Assembly	7-13
5600 Circuit Board.....	7-15
Miscellaneous	8-1
Leveling Feet	8-3
Accessories.....	8-4
Numerical Index	9-1
Alphabetical Index	10-1

BLANK PAGE


SECTION 1 Locators



H108_0266DCA
H108_0266DA




H108_0267DCA
H108_0267DA



BLANK PAGE

SECTION 2
Covers and Panels




H108_0303ECA
H108_0316EA

Figure 2-1 Top Cover and Panels
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	470153	Handle - Top cover	1	
2	852873	Washer	2	
3	852808	Screw	2	
4	918886	Cover - Top.....	1	
5	943716	Panel - Dryer.....	1	
6	981012	Spring - Hinge, drive side.....	1	
7	136224	E-Ring	2	
8	911716	Pin - Hinge, right-hand.....	1	
9	187235	Screw	6	
10	852961	Washer - Lock.....	6	
11	852616	Washer	6	
12	911713	Bracket - Hinge	1	
13	911714	Plate - Hinge, right-hand.....	1	
14	911717	Hinge - Nut, plate.....	2	
15	911715	Plate - Hinge, left-hand.....	1	
16	968443	Pin - Hinge, left-hand.....	1	
17	981013	Spring - Hinged, non-drive side.....	1	
18	943717	Panel - Access, receive end.....	1	
19	779336	Tray - Film exit.....	1	
20	981018	Panel - Side, plastic, complete	2	
	981751	Screw - Panel	2	Not Shown
	943707	Retainer.....	2	Not Shown


Figure 2-1 Top Cover and Panels
Order by Part Number



H108_0122DCA
H108_0309DA

Item	Part No.	Description	Qty.
1	852972	Screw	3
2	458478	Handle	2
3	202888	Retainer.....	2
4	499753	Retainer.....	2
5	261619	Screw - Panel	2
6	918884	Panel - Side, aluminum, complete.....	2


Figure 2-2 Side Panels (Old Style)
Order by Part Number



H108_0123DCA
H108_0123DA


Item	Part No.	Description	Qty.
1	914308	Panel - Access	1
2	852946	Screw	13
3	853100	Washer - Lock.....	13
4	852611	Washer	13
5	981008	Panel - Access transformer	1
6	468535	Adapter - Exhaust	1
7	852522	Screw	2

Figure 2-3 Feed End Panels
Order by Part Number



Item	Part No.	Description	Qty.
1	911640	Shelf - Feed, complete	1
2	454027	Film Guide Assembly.....	1
3	852611	Washer	5
4	853100	Washer - Lock.....	5
5	852888	Screw	5
6	144097	Nut - Wing.....	3
7	853011	Washer	3


Figure 2-4 Feed Tray
Order by Part Number



H108_0298DCB
H108_0298DA

Item	Part No.	Description	Qty.	Notes
1	914784	Bezel - Filter.....	1	
2	981007	Guard - Splash, drive side.....	1	
	852682	Screw	1	Not shown
	852611	Washer	1	Not shown
	853100	Washer - Lock.....	1	Not shown
3	943525	Guard - Splash, end	1	

Figure 2-5 Splash Guard
Order by Part Number




H108_0125CCC
H108_0125CA

Item	Part No.	Description	Qty.
1	914313	Cover - Dryer blower motor	1
2	522368	Guard - Pump	1
3	852835	Screw	1
4	852831	Washer	1

Figure 2-6 Recirculation Pump Guard and Dryer Blower Motor Cover
Order by Part Number

SECTION 3
Roller Transport System




H108_0302DA

**Figure 3-1 Rack Positions
Order by Part Number**

Item	Part No.	Description	Qty.	Notes
		Crossover Rollers		
1	490109	Roller - Detector, driven.....	1	Resilient, grooved
2	490108	Roller - Detector, drive.....	1	Resilient, grooved
3	240067	Roller Assembly	1	Resilient, smooth, driven; includes part no. 458384 & 544081
	458384	Gear - Idler.....	1	
	544081	Pin	1	
4	240066	Roller Assembly	1	Resilient, smooth, drive; includes part no. 458384 & 544081
	458384	Gear - Idler.....	1	
	544081	Pin	1	
5	467017	Roller Assembly	1	Driven
6	470085	Roller Assembly	1	Resilient, drive
		Rack Roller Assemblies		
7	470086	Roller - G	2	Drive
8	475453	Roller - T	1	Resilient; includes part no. 467564 & 539198
9	489695	Roller - H.....	11	Includes 489693 & 607833
	489693	Roller	32	
	607833	Sprocket	20	
10	489699	Roller - C.....	12	Includes part no. 489693, 467564, & 539198
	467564	Gear	21	
	539198	Idler	12	
11	492104	Roller - D.....	3	1.22 inch diameter
12	473146	Roller - B.....	2	Phenolic
12A	536884	Roller - B.....	1	Resilient
13	261279	Roller - A.....	6	Turnaround. Includes 2 bearings, part no. 650711
14	489697	Roller - E.....	9	Includes part no. 489693, 467564, & 607833
15	474599	Roller - Rewet.....	2	Resilient
16	467015	Roller - F	2	Stainless steel
17	246916	Roller - Pressure, driven.....	1	
18	246915	Roller - Pressure, drive.....	1	

Figure 3-1 Rack Positions
Order by Part Number




H108_0302DA

**Figure 3-1 Rack Positions
Order by Part Number**

Item	Part No.	Description	Qty.	Notes
		Squeegee Assembly Rollers		
5	467017	Roller Assembly	8	
6	470085	Roller Assembly	1	Drive, resilient
19	458423	Roller Assembly - J.....	1	Includes part no. 458389
20	467016	Roller Assembly - K.....	1	
21	458949	Roller Assembly - L & N.....	2	Includes part no. 458389
		Dryer Transport Rollers and Air Tubes.....		
22	286949	Dryer Transport Roller Assembly	23	Includes part no. 459379, 456162, 458901, & 852847
	459379	Roller	23	
	456162	Shaft	23	
	458901	Pulley.....	23	
	852847	Setscrew.....	23	
23	471397	Tube - Air	20	
24	968180	Roller - Turnaround.....	1	

Figure 3-1 Rack Positions
Order by Part Number




H108_0131BCA
H108_0131BA


Item	Part No.	Description	Qty.
1	489693	Roller	1
2	467563	Idler	1
3	467564	Gear	1
4	607833	Sprocket	1

Figure 3-2 Basic Roller Assembly
Order by Part Number

Figure 3-3 Detector Crossover Assembly



H048_0057DA




H048_0058DCA
H048_0058DA

Figure 3-4 Detector Crossover - Drive Side
Order by Part Number

Item	Part No.	Description	Qty.
	240683	Detector Crossover Assembly	1
1	490109	Roller - Detector, driven.....	1
2	458175	Shaft.....	1
3	458394	Rod - Tie	1
4	246879	Sideplate - Detector crossover	1
5	852807	Screw	1
6	650707	Bearing	1
7	472592	Bearing - Rocker.....	1
8	489997	Standoff - Pivot	1
9	474180	Support.....	1
10	650876	Actuator - Magnetic.....	1
11	575822	Washer	1
12	187283	Washer - Lock.....	1
13	575821	Screw	1
14	852682	Screw	2
15	853087	Washer - Lock.....	2
16	852611	Washer	2
17	165627	Washer	1
18	853096	Washer - Lock.....	1
19	544194	Screw	1
20	550781	Gear - Drive, crossover	1
21	452044	Key	1
22	458174	Spacer - Sleeve	1
23	650703	Bearing	1
24	183322	Screw	1
25	472756	Nut - Tie Rod, nylon	1
26	474596	Bracket - Guide shoe.....	1
27	852941	Screw	1
28	458953	Shoe - Guide.....	1
29	458170	Rod - Tie	1
30	458235	Shaft - Drive	1
31	490108	Roller - Detector, drive.....	1

Figure 3-4 Detector Crossover - Drive Side
Order by Part Number



H048_0059DCA
H048_0059DA


Figure 3-5 Detector Crossover - Non-Drive Side
Order by Part Number

Item	Part No.	Description	Qty.
	240683	Detector Crossover Assembly	1
1	490108	Roller - Detector, drive.....	1
2	458235	Shaft - Drive.....	1
3	458170	Rod - Tie	1
4	458953	Shoe - Guide.....	1
5	852941	Screw	1
6	474596	Bracket - Guide shoe.....	1
7	472755	Nut - Long.....	1
8	183322	Screw	1
9	458236	Spacer	1
10	852611	Washer	2
11	853087	Washer - Lock.....	2
12	852682	Screw	2
13	650703	Bearing.....	1
14	165627	Washer	1
15	853096	Washer - Lock.....	1
16	544194	Screw	1
17	575821	Screw	1
18	187283	Washer - Lock.....	1
19	575822	Washer	1
20	650876	Actuator - Magnetic.....	1
21	474180	Support.....	1
22	489997	Standoff - Pivot	1
23	472592	Bearing - Rocker.....	1
24	650707	Bearing.....	1
25	852807	Screw	1
26	246879	Sideplate - Detector crossover	1
27	458394	Rod - Tie	1
28	458175	Shaft.....	1
29	490109	Roller - Detector, driven.....	1

Figure 3-5 Detector Crossover - Non-Drive Side
Order by Part Number

BLANK PAGE

Figure 3-6 Developer Rack Assembly



H048_0045DA





Figure 3-7 Developer Rack - Top Exit Rollers
Order by Part Number

Item	Part No.	Description	Qty.	Notes
	240680	Developer Rack Assembly.....	1	
1	473539	Spacer.....	1	
2	559787	Shaft.....	1	
3	459378	Tie Rod Assembly.....	1	Includes item 13
4	470086	Roller - G.....	1	
5	454354	Key.....	3	
6	459355	Spacer.....	1	
7	459263	Chain.....	1	
8	454285	Sprocket.....	1	
9	463100	Washer - Thrust.....	3	
10	459943	Washer - ID.....	1	
11	463004	Spacer.....	2	
12	467843	Spring.....	2	
13	852807	Screw.....	12	
14	473538	Spacer.....	1	
15	550774	Gear.....	1	
16	852682	Screw.....	4	
17	853087	Washer - Lock.....	4	
18	852611	Washer.....	2	
19	473221	Plate - Keeper.....	2	
20	183624	Screw.....	4	
21	286907	Sideplate - Developer, drive.....	1	Includes item 20
22	467015	Roller - F.....	1	Includes a gear and 2 bearings
	650711	Bearing.....	2	
	466556	Gear.....	1	
23	458207	Shaft.....	1	
24	459347	Collar.....	2	
25	852889	Setscrew.....	2	
26	474599	Roller - Rewet.....	1	
27	458219	Rod - Tie.....	4	
28	286904	Sideplate - Developer, non-drive.....	1	Includes item 20
29	650702	Bearing.....	2	
30	473220	Bushing.....	2	
31	458205	Spacer.....	1	

Figure 3-7 Developer Rack - Top Exit Rollers
Order by Part Number




H108_0312DCA
H048_0047DA

Figure 3-8 Developer Rack - Other Rollers
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	489693	Roller	16	Roller only; C, E, or H
2	607833	Sprocket	11	
3	474777	Stud	35	
4	539198	Idler	7	
5	467564	Gear	11	
		Assemblies		
	489695	Roller - H.....	7	Includes items 1 & 2
	475453	Roller - T.....	1	Includes items 5, 6, & 7
	489699	Roller - C.....	5	Includes items 1, 5, & 7
6	492104	Roller - D.....	1	Assembly; includes the gear and idler
	489697	Roller - E.....	4	Includes items 1, 2, & 7

Figure 3-8 Developer Rack - Other Rollers
Order by Part Number



H048_0048ECA
H048_0048EA


Figure 3-9 Developer Rack - Turnaround Rollers
Order by Part Number

Item	Part No.	Description	Qty.	Notes
	335977	Developer Turnaround Assembly	1	
1	474596	Bracket - Guide shoe.....	6	
2	852941	Screw	6	
3	458228	Shoe - Guide.....	2	
4	261279	Roller - A.....	2	Includes item 18
5	458207	Shaft	3	
6	536884	Roller - B.....	1	
7	650702	Bearing	2	
8	459263	Chain	1	
9	286907	Sideplate - Developer, drive	1	Includes item 10
10	183624	Screw	4	
11	490096	Screw	4	
12	477001	Sideplate - Drive	1	
13	183322	Screw	6	
14	852682	Screw	6	
15	472265	Plate - Locking	1	
16	190596	Screw	2	
17	474645	Spring	2	
18	650711	Bearing	4	
19	562765	Shoe - Guide.....	1	
20	477000	Sideplate - Non-drive	1	
21	463100	Washer - Thrust	6	
22	463004	Spacer	6	
23	459343	Washer - Flat	6	
24	286904	Sideplate - Developer, non-drive	1	Includes item 10

Figure 3-9 Developer Rack - Turnaround Rollers
Order by Part Number

BLANK PAGE

Figure 3-10 Developer/Fixer Crossover Assembly



H048_0060DA





Figure 3-11 Developer/Fixer Crossover - Drive Side
Order by Part Number

Item	Part No.	Description	Qty.	Notes
	240684	Developer/Fixer Crossover Assembly.....	1	
1	458954	Shoe - Guide.....	1	Developer side
2	852941	Screw	4	
3	474596	Bracket - Guide shoe.....	4	
4	458170	Rod - Tie	2	
5	286900	Sideplate - Crossover	2	
6	472268	Clip	2	
7	472756	Nut - Tie Rod, nylon	2	
8	183322	Screw	6	
9	459946	Washer - ID.....	1	
10	853087	Washer - Lock.....	4	
11	852682	Screw	4	
12	550781	Gear - Drive, crossover	1	
13	452044	Key	1	
14	852611	Washer	2	
15	240065	Spacer.....	1	
16	459344	Spring	2	
17	240060	Bearing	2	
18	240061	Bearing	2	
19	458953	Shoe - Guide.....	1	Fixer side
20	458384	Gear - Idler.....	2	
21	240066	Roller Assembly	1	
22	240067	Roller Assembly	1	
23	544081	Pin	2	Drive; includes items 20 & 23
				Driven; includes items 20 & 23

Figure 3-11 Developer/Fixer Crossover - Drive Side
Order by Part Number



H048_0062DCA
H048_0062DA


Figure 3-12 Developer/Fixer Crossover - Non-Drive Side
Order by Part Number

Item	Part No.	Description	Qty.	Notes
	240684	Developer/Fixer Crossover Assembly.....	1	
1	852941	Screw	4	
2	458954	Shoe - Guide.....	1	Developer side
3	474596	Bracket - Guide shoe.....	4	
4	240067	Roller Assembly	1	Driven
5	240066	Roller Assembly	1	Drive
6	458953	Shoe - Guide.....	1	Fixer side
7	286900	Sideplate - Crossover	2	
8	183322	Screw	4	
9	240061	Bearing	2	
10	240060	Bearing	2	
11	459344	Spring	2	
12	852611	Washer	2	
13	853087	Washer - Lock.....	4	
14	852682	Screw	4	
15	472268	Clip	2	
16	472755	Nut - Long	2	
17	458170	Rod - Tie	2	

Figure 3-12 Developer/Fixer Crossover - Non-Drive Side
Order by Part Number

BLANK PAGE

Figure 3-13 Fixer Rack Assembly



H048_0049DA





Figure 3-14 Fixer Rack - Top Exit Rollers
Order by Part Number

Item	Part No.	Description	Qty.	Notes
	335534	Fixer Rack Assembly	1	
1	473539	Spacer	1	
2	559787	Shaft	1	
3	459378	Tie Rod Assembly	1	Includes item 11
4	470086	Roller - G	1	
5	454354	Key	3	
6	459355	Spacer	1	
7	462688	Chain	1	
8	454285	Sprocket	1	
9	463100	Washer - Thrust	3	
10	459944	Washer - ID	1	
11	852807	Screw	6	
12	463004	Spacer	2	
13	467843	Spring	2	
14	473538	Spacer	1	
15	550774	Gear	1	
16	852682	Screw	4	
17	853087	Washer - Lock	4	
18	852611	Washer	2	
19	473221	Plate - Keeper	2	
20	183624	Screw	4	
21	286917	Sideplate - Fixer, drive	1	Includes item 20
22	467015	Roller - F	1	Includes a gear and 2 bearings
	650711	Bearing	2	
	466556	Gear	1	
23	458207	Shaft	1	
24	459347	Collar	2	
25	852889	Setscrew	2	
26	474599	Roller - Rewet	1	
27	458219	Rod - Tie	4	
28	286914	Sideplate - Fixer, non-drive	1	Includes item 20
29	650702	Bearing	2	
30	473220	Bushing	2	
31	458205	Spacer	1	

Figure 3-14 Fixer Rack - Top Exit Rollers
Order by Part Number




H108_0310DCA
H108_0310DA

Figure 3-15 Fixer Rack - Other Rollers
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	489693	Roller	11	Roller only; C, E, or H
2	607833	Sprocket	7	
3	474777	Stud	24	
4	539198	Idler	4	
5	467564	Gear	7	
		Assemblies		
	489695	Roller - H.....	4	Includes items 1 & 2
	489699	Roller - C.....	4	Includes items 1, 4, & 6
	492104	Roller - D.....	1	Assembly; includes the gear and idler
	489697	Roller - E.....	3	Includes items 1, 2, & 4
	261892	Roller - Z.....	1	Includes items 4 & 5

Figure 3-15 Fixer Rack - Other Rollers
Order by Part Number



H048_0052ECA
H048_0052EA


Figure 3-16 Fixer Rack - Turnaround Rollers
Order by Part Number

Item	Part No.	Description	Qty.	Notes
	748699	Turnaround Assembly	1	Includes all items on this page except 9, 10, & 24
1	474596	Bracket - Guide shoe	6	
2	852941	Screw	6	
3	458228	Shoe - Guide	2	
4	261279	Roller - A	2	Includes item 18
5	458207	Shaft	3	
6	473146	Roller - B	1	
7	650702	Bearing	2	
8	462688	Chain	1	
9	286917	Sideplate - Fixer, drive	1	Includes item 10
10	183624	Screw	4	
11	490096	Screw	4	
12	477001	Sideplate - Drive	1	
13	183322	Screw	6	
14	852682	Screw	6	
15	472265	Plate - Locking	1	
16	190596	Screw	2	
17	474645	Spring	2	
18	650711	Bearing	4	
19	562765	Shoe - Guide	1	
20	477000	Sideplate - Non-drive	1	
21	463100	Washer - Thrust	6	
22	463004	Spacer	6	
23	459343	Washer - Flat	6	
24	286914	Sideplate - Fixer, non-drive	1	Includes item 10


Figure 3-16 Fixer Rack - Turnaround Rollers
Order by Part Number

BLANK PAGE

Figure 3-17 Fixer/Wash Crossover Assembly



H108_0305DA




H108_0306DCA
H108_0306DA

Figure 3-18 Fixer/Wash Crossover - Drive Side
Order by Part Number

Item	Part No.	Description	Qty.	Notes
	240685	Fixer/Wash Crossover Assembly.....	1	
1	458954	Shoe - Guide.....	1	Fixer side
2	852941	Screw	4	
3	474596	Bracket - Guide shoe.....	4	
4	458170	Rod - Tie	2	
5	286900	Sideplate - Crossover	2	
6	472268	Clip	2	
7	472756	Nut - Tie Rod, nylon	2	
8	183322	Screw	6	
9	459947	Washer - ID.....	1	
10	853087	Washer - Lock.....	4	
11	852682	Screw	4	
12	550781	Gear - Drive, crossover	1	
13	452044	Key	1	
14	852611	Washer	2	
15	458174	Spacer - Sleeve	1	
16	650703	Bearing	2	
17	650707	Bearing	2	
18	943700	Insert - Quick disconnect.....	1	
19	246725	Header - Spray	1	Wash side
20	458164	Shaft - Drive	1	
21	470085	Roller Assembly	1	Drive
22	458175	Shaft.....	1	
23	467017	Roller Assembly	1	Driven

Figure 3-18 Fixer/Wash Crossover - Drive Side
Order by Part Number



H108_0307DCA
H108_0307DA


Figure 3-19 Fixer/Wash Crossover - Non-Drive Side
Order by Part Number

Item	Part No.	Description	Qty.	Notes
	240685	Fixer/Wash Crossover Assembly.....	1	
1	852941	Screw	4	
2	458954	Shoe - Guide.....	1	Fixer side
3	474596	Bracket - Guide shoe.....	4	
4	467017	Roller Assembly	1	Driven
5	458175	Shaft	1	
6	470085	Roller Assembly	1	Drive
7	458164	Shaft - Drive	1	
8	246725	Header - Spray	1	Wash side
9	286900	Sideplate - Crossover	2	
10	183322	Screw	4	
11	650707	Bearing	2	
12	650703	Bearing	2	
13	852611	Washer	3	
14	853087	Washer - Lock.....	4	
15	852682	Screw	4	
16	472268	Clip	2	
17	472755	Nut - Long	2	
18	458170	Rod - Tie	2	


Figure 3-19 Fixer/Wash Crossover - Non-Drive Side
Order by Part Number

BLANK PAGE

Figure 3-20 Wash Rack Assembly



H048_0053DA



H048_0054ECA
H048_0054EA

Figure 3-21 Wash Rack - Squeegee Rollers
Order by Part Number

Item	Part No.	Description	Qty.	Notes
	240682	Wash Rack Assembly	1	
1	474100	Spacer	3	
2	479820	Spring	2	
3	246915	Roller - Pressure, drive	1	
4	459378	Tie Rod Assembly	1	Includes item 12
5	544081	Pin	2	
6	458384	Gear - Idler	2	
7	458240	Chain	1	
8	454285	Sprocket	1	
9	454354	Key	2	
10	463100	Washer - Thrust	1	
11	459945	Washer - ID	1	
12	852807	Screw	2	
13	650702	Bearing	2	
14	473538	Spacer	1	
15	550774	Gear	1	
16	852611	Washer	2	
17	852682	Screw	4	
18	853087	Washer - Lock	4	
19	459343	Washer - Flat	2	
20	650701	Bearing	2	
21	183624	Screw	4	
22	286912	Sideplate - Wash, drive	1	Includes item 21
23	246916	Roller - Pressure, driven	1	
24	477093	Spacer	1	
25	286910	Sideplate - Wash, non-drive	1	Includes item 21
26	458205	Spacer	1	

Figure 3-21 Wash Rack - Squeegee Rollers
Order by Part Number





Figure 3-22 Wash Rack - Other Rollers
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	474472	Guide Bar Assembly	1	Roller only; C or E
2	467564	Gear	5	
3	489693	Roller	5	
4	539198	Idler	3	
5	474777	Stud	12	
6	607833	Sprocket	2	
7	492104	Roller - D.....	1	
8	852682	Screw	1	
		Assemblies		
	489699	Roller - C.....	3	Includes items 2 - 4
	489697	Roller - E.....	2	Includes items 2, 3, & 6

Figure 3-22 Wash Rack - Other Rollers
Order by Part Number



H048_0056ECA
H048_0056EA


Figure 3-23 Wash Rack - Turnaround Rollers
Order by Part Number

Item	Part No.	Description	Qty.	Notes
	748699	Turnaround Assembly	1	
1	458207	Shaft	3	
2	473146	Roller - B.....	1	
3	474596	Bracket - Guide shoe.....	6	
4	852941	Screw	6	
5	458228	Shoe - Guide.....	2	
6	261279	Roller - A.....	2	Includes item 18
7	459263	Chain	1	
8	286912	Sideplate - Wash, drive	1	Includes item 10
9	650702	Bearing	2	
10	183624	Screw	4	
11	490096	Screw	4	
12	477001	Sideplate - Drive	1	
13	183322	Screw	6	
14	852682	Screw	4	
15	472265	Plate - Locking	1	
16	190596	Screw	2	
17	474645	Spring	2	
18	650711	Bearing	2	
19	562765	Shoe - Guide.....	1	
20	477000	Sideplate - Non-drive	1	
21	463100	Washer - Thrust	4	
22	463004	Spacer	4	
23	459343	Washer - Flat	4	
24	286910	Sideplate - Wash, non-drive	1	Includes item 10


Figure 3-23 Wash Rack - Turnaround Rollers
Order by Part Number

BLANK PAGE

Figure 3-24 Squeegee Assembly



H048_0066DA




H048_0067DCA
H048_0067DA

Figure 3-25 Squeegee Assembly - Drive Side
Order by Part Number

Item	Part No.	Description	Qty.	Notes
	240686	Squeegee Assembly	1	
1	458954	Shoe - Guide.....	2	
2	852941	Screw	4	
3	474596	Bracket - Guide shoe.....	2	
4	458170	Rod - Tie	1	
5	286922	Sideplate - Squeegee	2	
6	472756	Nut - Tie Rod, nylon	1	
7	183322	Screw	8	
8	914507	Bearing	2	
9	459344	Spring	2	
10	462139	Washer	1	
11	853087	Washer - Lock.....	2	
12	852682	Screw	2	
13	458174	Spacer - Sleeve	1	
14	550781	Gear - Drive, crossover	1	
15	452044	Key	1	
16	852611	Washer	2	
17	852807	Screw	8	
18	650705	Bearing	6	
19	458389	Bearing	2	
20	458175	Shaft	1	
21	467017	Roller Assembly	3	
22	458394	Rod - Tie	3	
23	458391	Shaft	2	
24	458949	Roller Assembly - L & N.....	1	Includes item 19
25	458390	Shaft	2	
26	458393	Shaft	1	
27	467016	Roller Assembly - K.....	1	
28	458423	Roller Assembly - J.....	1	Includes item 19
29	458162	Bracket - Guide Shoe	2	
30	470085	Roller Assembly	1	Drive
31	458235	Shaft - Drive	1	

Figure 3-25 Squeegee Assembly - Drive Side
Order by Part Number



H048_0068EAA
H048_0068EA

Figure 3-26 Squeegee Assembly - Non-Drive Side
Order by Part Number


Item	Part No.	Description	Qty.	Notes
	240686	Squeegee Assembly	1	
1	458170	Rod - Tie	1	
2	474596	Bracket - Guide shoe	2	
3	852941	Screw	4	
4	458954	Shoe - Guide	2	
5	458390	Shaft	2	
6	467017	Roller Assembly	3	
7	458235	Shaft - Drive	1	
8	470085	Roller Assembly	1	Drive
9	458162	Bracket - Guide Shoe	2	
10	458394	Rod - Tie	3	
11	458387	Spacer	2	
12	458391	Shaft	2	
13	458389	Bearing	2	
14	458423	Roller Assembly - J	1	Includes item 13
15	467016	Roller Assembly - K	1	
16	458949	Roller Assembly - L & N	2	Includes item 13
17	458393	Shaft	1	
18	458382	Gear	2	
19	458175	Shaft	1	
20	286922	Sideplate - Squeegee	2	
21	650705	Bearing	6	
22	852611	Washer	2	
23	853087	Washer - Lock	2	
24	852682	Screw	2	
25	852807	Screw	8	
26	458208	Washer	4	
27	458389	Bearing	2	
28	183322	Screw	8	
29	180977	Washer - Flat	1	
30	458385	Gear - 29-Tooth	1	
31	458386	Screw - Shoulder	1	
32	458236	Spacer	1	
33	459344	Spring	2	
34	914507	Bearing	2	
35	472755	Nut - Long	1	

Figure 3-26 Squeegee Assembly - Non-Drive Side
Order by Part Number


BLANK PAGE

SECTION 4

Main Drive Assembly



H108_0276DA




H108_0275DCA
H108_0275DA

Figure 4-1 Main Drive Assembly
Order by Part Number

Item	Part No.	Description	Qty.
1	472315	Shaft.....	1
2	650663	Gear	1
3	853051	Ring - Retaining.....	1
4	852520	Screw	2
5	535004	Washer - Lock.....	2
6	183498	Washer - Flat	2
7	968199	Stud - Special	1
8	963435	Bearing.....	2
9	963969	Pivot Assembly	1
10	963965	Roller - Idler	2
11	459343	Washer - Flat	1
12	850897	Washer - Lock.....	1
13	852972	Screw	1
14	968197	Idler - Shaft	1
15	562201	Screw - Countersink	1
16	852522	Screw	1
17	190481	Bearing - Ball	2
18	968434	Roller - Drive, crowned	1
19	968433	Belt	1
20	853069	Pin	1
21	853186	Screw	1
22	852630	Washer	1
23	779728	Bushing	1
24	943202	Roller - Idler	1
25	852941	Screw	1
26	968446	Spacer - Spring, belt tensioner.....	1
27	968445	Spring - Belt tensioner.....	1
28	748955	Gear - Worm, left-hand.....	1
29	458187	Sprocket.....	1
30	911150	Chain.....	1
31	852558	Setscrew.....	1


Figure 4-1 Main Drive Assembly
Order by Part Number



H108_0028DCB
H108_0028DA

Item	Part No.	Description	Qty.
1	748955	Gear - Worm, left-hand.....	5
2	748956	Gear - Right, hand worm.....	3
3	853000	Pin	8
4	472446	Shaft.....	1
5	246612	Bar - Rack support.....	1
6	472192	Support.....	1
7	192019	Bearing	2
8	472989	Collar	2
9	852845	Setscrew.....	4
10	535004	Washer - Lock.....	4
11	852520	Screw	4


Figure 4-2 Main Drive
Order by Part Number



H108_0274DCB
H108_0274DA

Item	Part No.	Description	Qty.
1	955703	Motor - DC Drive	1
2	587227	Nut.....	4
3	852961	Washer - Lock.....	4
4	779325	Gearbox	1
5	968195	Bracket - Motor, mount	1
6	914518	Screw	4
7	852558	Setscrew.....	1
8	779729	Sprocket - Drive	1
9	911150	Chain	1
10	246800	Clamp - Hose, narrow band size 2, range .219 - .625m, width .312	2
11	943701	Coupling - Quick disconnect, panel mount	1
12	594534	Washer - Metal	1
13	943700	Insert - Quick disconnect.....	1
14	171950	Screw	2
15	852961	Washer - Lock.....	2
16	852873	Washer	2

**Figure 4-3 Main Drive
Order by Part Number**




H108_0273DCC
H108_0273DA

Item	Part No.	Description	Qty.
1	466641	Support.....	2
2	852805	Screw	4
3	246612	Bar - Rack support	1
4	963962	Level Sensing Assembly.....	1
5	182098	Setscrew.....	2
6	968067	Tank	1

Figure 4-4 Rack Support Bar
Order by Part Number


SECTION 5
Dryer Assembly



H108_0026DCA
H108_0026DA

Item	Part No.	Description	Qty.
1	246807	Clamp - Band.....	1
2	748449	Hose.....	1
3	911428	Blower - Exhaust.....	1
4	852611	Washer.....	2
5	853100	Washer - Lock.....	2
6	852682	Screw	2

Figure 5-1 Dryer Assembly
Order by Part Number




H108_0315DCA
H108_0315DA

Figure 5-2 Dryer Rollers and Air Tubes
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	562609	Spring	20	Includes: 456162 Shaft 459379 Roller 852857 Setscrew 458901 Pulley
2	779232	Tube - Air	20	
3	459379	Roller	23	
4	286949	Dryer Transport Roller Assembly	23	
5	456162	Shaft	24	Not shown Not shown
6	562670	Block	44	
	852857	Setscrew	23	
	458901	Pulley	23	
7	968179	Panel - Ribbed	1	
	852682	Screw	1	
	852611	Washer	1	
	853100	Washer - Lock	1	

Figure 5-2 Dryer Rollers and Air Tubes
Order by Part Number




H108_0258ECB
H108_0258EA

Figure 5-3 Dryer Rollers and Air Tubes
Order by Part Number

Item	Part No.	Description	Qty.
1	467017	Roller Assembly	5
2	963974	Shaft - Turnaround, drive.....	1
3	458901	Pulley.....	1
4	963808	Shaft.....	5
5	458952	Setscrew.....	5
6	963806	Shoe.....	2
7	852808	Screw	4
8	968073	Block - Shoe, mounting	4
9	852809	Screw	4
10	850897	Washer - Lock.....	6
11	180977	Washer - Flat	4
12	918877	Bearing Block Assembly - Right.....	1
13	968180	Roller - Turnaround.....	1
14	963622	Bearing Block Assembly - Left	1
15	458384	Gear - Idler.....	2
16	968444	Spacer	2
17	779051	Washer - Flat	2
18	852810	Screw	2


Figure 5-3 Dryer Rollers and Air Tubes
Order by Part Number



H108_0042ECC
H108_0042EA

Item	Part No.	Description	Qty.
1	659590	Thermostat - Overtemperature	1
2	911438	Strip - Terminal	1
3	493400	Relief - Strain	1
4	852073	Locknut.....	1
5	183153	Heater.....	2
6	852611	Washer	6
7	853100	Washer - Lock.....	6
8	852682	Screw	6
9	622026	Bracket - Heater	2
10	852971	Screw	2
11	187213	Washer - Lock.....	2
12	968186	Cover - Heater	1


Figure 5-4 Heater Parts
Order by Part Number



H108_0041DCA
H108_0041DA

Item	Part No.	Description	Qty.
1	474692	Pulley - Blower	1
2	852559	Setscrew	4
3	474442	Belt	1
4	963611	Motor - Blower	1
5	474693	Pulley.....	1
6	853006	Screw	6
7	852617	Washer - Lock.....	6
8	852613	Washer	6
9	470203	Bearing Assembly	2
10	914310	Guard	1
11	166331	Nut.....	4
12	852656	Washer - Lock.....	4
13	852615	Washer	4
14	264983	Blower	1

Figure 5-5 Blower and Motor Assembly
Order by Part Number



H108_0255dca
P108_0255DA


Item	Part No.	Description	Qty.
1	541262	Screw	2
2	852630	Washer	2
3	779749	Sleeve	2
4	779727	Pulley.....	2
5	968433	Belt	1

Figure 5-6 Lower Dryer Adjustment Assembly
Order by Part Number

SECTION 6
Plumbing

Item	Part No.	Description	Qty.
1	246800	Clamp - Hose, narrow band size 2, range .219 - .625m, width .312	10
2	911483	Tubing	1
		Developer Drain Assembly	1
3	583127	Valve - Chemical drain	1
4	748249	Elbow - ½ x ¾ in.....	1
5	748427	Nipple - ½ x 2 ½ in.....	2
6	748585	Tee - ½ x ¾ x ¾ in.....	1
7	748245	Clamp.....	1
8	534764	Elbow - ½ Pt x ½ Barb	1
9	475492	Cap.....	1
10	246808	Clamp - Hose, wide band size 10, range .500 - 1.125 width .562.....	1
11	914498	Tubing - Formed	2
12	607748	Thermowell.....	1
13	918889	Orifice, .220 I D.....	1
14	914491	Recirculation Pump Assembly	1
15	760476	Tubing	1
16	240628	Tubing - Formed	1
17	562790	Cartridge - Filter.....	1
18	261391	Canister - Developer filter.....	1
19	562553	Filter Cap Assembly	1
20	333966	Tubing - Formed	1
21	943211	Replenishment Pump Assembly, complete.....	1
22	333439	Tubing - Flared	1
23	479821	Cylinder - Graduated	1
24	240888	Valve - Replenishment, check.....	1
25	943205	Tubing - Formed	1
26	429715	Clamp - Hose, narrow band size 2, range .359 - .391, width .220	3

Figure 6-1 Developer Circulation Plumbing Diagram
Order by Part Number




H108_0261ECB
H108_0261EA

Figure 6-2 Fixer Circulation Plumbing Diagram
Order by Part Number

Item	Part No.	Description	Qty.
1	333465	Tubing - Formed, 13.0 in.....	1
2	607748	Thermowell.....	1
3	911485	Tubing - Formed, flared.....	1
4	918889	Orifice, .220 I D.....	1
5	914491	Recirculation Pump Assembly.....	1
6	246808	Clamp - Hose, wide band size 10, range .500 - 1.125 width .562.....	17
		Drain Valve Assembly	1
7	583127	Valve - Chemical drain	1
8	748249	Elbow - ½ x ¾ in.....	1
9	748427	Nipple - ½ x 2 ½ in.....	2
10	748585	Tee - ½ x ¾ x ¾ in.....	1
11	748245	Clamp.....	1
12	534764	Elbow - ½ Pt x ½ Barb	1
13	475492	Cap.....	1
14	459600	Tubing	1
15	246890	Tubing - Formed	1
16	943211	Replenishment Pump Assembly, complete.....	1
17	475499	Fitting Tee ½ x ½ x ¼.....	1
17	429715	Clamp - Hose, narrow band size 2, range .359 - .391, width .220	1
18	240888	Valve - Replenishment, check.....	1
19	333439	Tubing - Flared	1
20	464101	Tubing - 13.0 in.....	1

Figure 6-2 Fixer Circulation Plumbing Diagram
Order by Part Number




H108_0262DCB
H108_0262DA

Figure 6-3 Washer Circulation Plumbing Diagram
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	532095	Exchanger - Heat.....	1	Not shown, packed in prepack
2	532378	Seal	6	
3	532379	Washer	2	
4	562602	Plug - Gland sealing	2	
5	333432	Tubing- Formed.....	1	
6	911151	Coupling - Drain.....	1	
7	183882	Adapter.....	1	
8	853063	Fitting - Barbed	1	
9	282902	Tee - ½ PT x ½ Barb x ½ Barb.....	1	
10	246808	Clamp - Hose, wide band size 10, range .500 - 1.125 width .562.....	17	
11	911487	Tubing - Formed	1	
12	779243	Solenoid - Cooling/wash dump.....	1	
13	963809	Tubing - Formed, flared	1	
14	594431	Adapter - Garden hose	1	
15	779241	Solenoid Valve - Inlet.....	1	
16	911480	Tubing - Formed, flared	1	
17	911486	Tubing - Flared, 53 in., high pressure.....	1	
18	475492	Cap.....	1	
19	943701	Coupling - Quick disconnect, panel mount.....	1	
20	246801	Clamp - Hose, narrow band size 3	2	
21	581094	Washer - Garden hose	1	

Figure 6-3 Washer Circulation Plumbing Diagram
Order by Part Number




H108_0157ECB
H108_0157EA

Figure 6-4 Developer/Fix Thermowell Assemblies
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	183498	Washer - Flat	4	Not shown
2	535004	Washer - Lock.....	4	Not shown
3	852871	Screw	4	Not shown
4	607748	Thermowell	2	
5	779243	Solenoid - Cooling/wash dump.....	1	
6	618502	Diode Assembly	1	
7	914804	Heater - Developer, 1000 watts.....	1	
8	914803	Heater - Fixer, 1200 watts	1	
9	246808	Clamp - Hose, wide band size 10, range .500 - 1.125 width .562.....	4	
10	541891	Plug	2	
11	529615	Label - Fixer	1	
12	963610	Thermistor	2	
13	607793	Locator	2	Not shown
14	532033	Adapter	2	
15	522359	Label - Developer	1	


Figure 6-4 Developer/Fix Thermowell Assemblies
Order by Part Number



H108_0242DCA
H108_0242DA

Item	Part No.	Description	Qty.	Notes
1	246746	Bracket	1	Includes 562485 O-Ring
2	852682	Screw	2	
3	853100	Washer - Lock.....	2	
4	943208	Spacer	2	
5	261391	Canister - Developer filter	1	
6	562790	Cartridge - Filter.....	1	
7	562485	O-Ring	1	
8	562553	Filter Cap Assembly.....	1	


Figure 6-5 Filter Canister Assembly
Order by Part Number



H108_0040DCC
H108_0040DA

Item	Part No.	Description	Qty.	Notes
	911491	Recirculation Pump Assembly	1	
1	477871	Capacitor	1	
2	473926	Magnet - Drive	2	
3	418700	Housing - Inner	2	
4	463363	O-Ring	2	
5	474362	Impeller.....	2	
6	144097	Nut - Wing.....	8	
7	472606	Housing - Outer, right	1	
8	452946	Screw	2	
9	493505	Washer	2	
10	418701	Inner Housing and Impeller Assembly	2	Includes items 3, 4, 5, 8, and 9
11	852873	Washer	2	
12	853086	Washer - Lock.....	2	
13	852895	Screw	2	
14	472605	Housing - Outer, left	1	

Figure 6-6 Recirculation Pump Assembly
Order by Part Number




H108_0020DCB
H108_0020DA

Figure 6-7 Replenishment Control Assembly
Order by Part Number

Item	Part No.	Description	Qty.
1	478560	Switch - Replenishment, check	1
2	522359	Label - Developer	1
3	869623	Label - Modification.....	1
4	529615	Label - Fixer.....	1
5	479821	Cylinder - Graduated	2
6	240888	Valve - Replenishment, check	2

Figure 6-7 Replenishment Control Assembly
Order by Part Number




H108_0272DCB
H108_0272DA

Figure 6-8 Developer/Fixer Replenishment Pumps
Order by Part Number

Item	Part No.	Description	Qty.
1	520390	Elbow.....	2
2	520391	Nut.....	2
3	914807	Spring.....	1
4	520388	O-Ring.....	2
5	609817	Valve Assembly	2
6	535638	Valve Body.....	1
7	535639	O-Ring.....	2
8	914812	Guide.....	1
9	532008	Bellows.....	1
10	594838	Cup - Displacement	1
11	594839	Nut - Coupling.....	1
12	914809	Connecting Rod Assembly	1
13	914808	E-Ring	1
14	943211	Replenishment Pump Assembly, complete.....	2
15	914811	Crank.....	1

Figure 6-8 Developer/Fixer Replenishment Pumps
Order by Part Number




H108_0023DA

H108_0023DCB

Figure 6-9 Drain Assembly
Order by Part Number

Item	Part No.	Description	Qty.
1	282902	Tee - ½ PT x ½ Barb x ½ Barb.....	1
2	246808	Clamp - Hose, wide band size 10, range .500 - 1.125 width .562.....	17
3	911151	Coupling - Drain.....	1
4	183882	Adapter.....	1
5	853063	Fitting - Barbed	1
6	852682	Screw	4
7	853100	Washer - Lock.....	4
8	852611	Washer	4
9	779718	Panel	1
10	583127	Valve - Chemical drain	2
11	475492	Cap.....	2
12	748249	Elbow - ½ x ¾ in.....	2
13	748427	Nipple - ½ x 2 ½ in.....	4
14	534764	Elbow - ½ Pt x ½ Barb	2
15	748585	Tee - ½ x ¾ x ¾ in.....	2
16	246801	Clamp - Hose, narrow band size 3	2
17	748245	Clamp.....	2

Figure 6-9 Drain Assembly
Order by Part Number



H108_0127ECA
H108_0127EA


Figure 6-10 Developer Heat Exchanger
Order by Part Number

Item	Part No.	Description	Qty.
1	779730	Cover - Heat Exchanger	1
2	532095	Exchanger - Heat.....	1
3	532377	Washer	2
4	532378	Seal	2
5	562602	Plug - Gland sealing	1

Figure 6-10 Developer Heat Exchanger
Order by Part Number

BLANK PAGE


SECTION 7
Electrical



H108_0046ECB
P108_0046EA

Item	Part No.	Description	Qty.
1	911424	Filter - FL1, FL2, FL3.....	3
2	918801	Transformer - T1	1
3	918211	Filter - FL4	1
4	264407	Fuse - F3	1
5	264405	Holder - Fuse	1
6	911419	Breaker - Circuit, 10 A, CB2, CB4	2
7	779273	Breaker - Circuit, 15 A, CB3.....	1
8	914235	Strip - Marker	1
9	914234	Strip - Terminal, TB2	1
10	240627	Strip - Terminal, TB1	1

Figure 7-1 Transformer Box
Order by Part Number




H108_0284DCB
H108_0284DA

**Figure 7-2 Electrical Box
Order by Part Number**

Item	Part No.	Description	Qty.
1	535265	Strip - Terminal, TB5	1
2	955745	Quad Power Supply.....	1
3	911412	Controller - DC Motor	1
4	914493	Counter.....	1
5	968175	500 Circuit Board Assembly	1
6	781230	Filter - RFI.....	1
7	779400	Strip - Terminal	1
8	918804	Network - Arc suppression	1
9	918204	Relay - K8.....	1
10	779409	Transformer - T2.....	1
11	655290	Solid State Relay	5

Figure 7-2 Electrical Box
Order by Part Number




H108_0285DCB
H108_0285DA

Figure 7-3 500 Circuit Board Assembly
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	969175	500 Circuit Board Assembly, packed, does not include U17 - U20	1	Japanese All other languages
2	227322	Battery	1	
3	981011	U17, U18, U19	1	
3	981010	U17, U18, U19	1	
4	981099	U20.....	1	


Figure 7-3 500 Circuit Board Assembly
Order by Part Number



H108_0283DCA
H108_0283DA

Item	Part No.	Description	Qty.
1	422206	Receptacles - J9, J12, J13.....	1
2	558648	Receptacles - J14, J15, J10.....	1
3	911404	Receptacles - J4, J5, J6,J7, J8, J17, J100	4
4	911406	Receptacle - J3.....	1
5	911400	Connector - P2	1
6	273691	Fuse - F2, 2.5 Amp, slow-blow	1
7	379381	Fuse - F1, ¼ Amp, slow-blow.....	1
8	477506	Carrier - Fuse.....	2
9	498607	Holder - Fuse	2
10	379569	Receptacle - J18	1


Figure 7-4 Electrical Box
Order by Part Number



H108_0254ECD
H108_0254EA

Item	Part No.	Description	Qty.
1	852682	Screw	2
2	209234	Washer - Nylon	2
3	918097	200 Circuit Board Assembly	1
4	779234	Panel - Control	1
5	594466	Connector - Interface	1
6	943204	Bezel - Overlay	1
7	191097	Screw - Jack	6
8	852835	Screw	4
9	781405	Receptacle - 110 Volt	1
10	911420	Breaker - Circuit, 35 amp	1

Figure 7-5 Control Panel
Order by Part Number




H108_0286ECC
H108_0286EA

Figure 7-6 350 Circuit Board Display Assembly
Order by Part Number

Item	Part No.	Description	Qty.
1	981425	350 Circuit Board Display Assembly	1
2	852682	Screw	4
3	853100	Washer - Lock.....	4
4	183498	Washer - Flat	4

Figure 7-6 350 Circuit Board Display Assembly
Order by Part Number



H108_0279DCC
H108_0279DA


Figure 7-7 5600 Circuit Board Assembly
Order by Part Number

Item	Part No.	Description	Qty.	Notes
1	911425	5600 Circuit Board Assembly	1	Not shown
	968442	Eprom - U5612	1	
2	963624	Cover	1	
3	914545	Bracket - Switch, right.....	1	
4	914599	Reed Switch Assembly	2	
5	852835	Screw	4	
6	165627	Washer	4	
7	187213	Washer - Lock.....	4	
8	535561	Screw	2	
9	528291	Washer	2	
10	191098	Washer - Lock.....	2	
11	914544	Bracket - Switch, left.....	1	
12	288235	Strip - Tap	2	

Figure 7-7 5600 Circuit Board Assembly
Order by Part Number

BLANK PAGE


SECTION 8
Miscellaneous



H108_0270DCA
H108_0270DA

Item	Part No.	Description	Qty.	Notes
1	459229	Screw - Leveling	1	Not shown
2	459548	Plate - Floor	1	
3	261413	Earth Quake Bracket Kit, includes:	1	
4		Plate - Floor	4	
5		Anchor	8	
6		Bracket	4	
7		Bolt - Stainless steel	8	
8		Washer - Stainless steel	8	
		Punch	1	

Figure 8-1 Leveling Feet
Order by Part Number



H108_0253DCA
H108_0253DA

Item	Part No.	Description	Qty.
1	479821	Cylinder - Graduated	2
2	472261	Strainer Assembly, complete	2
3	744714	Plug - Adapter.....	1
4	955747	Cable - Adapter.....	1
5	650938	Gasket - Light tight, 10 ft. roll.....	2
6	459432	Tray - Drip.....	1
7	240864	Guard - Splash.....	1

Figure 8-2 Accessories
Order by Part Number

SECTION 9

Numerical Index

Part Number	Description	Figure Number
136224	E-Ring	2-1
144097	Nut - Wing	2-4, 6-6
165627	Washer	3-4, 3-5, 7-7
166331	Nut	5-5
171950	Screw	4-3
180977	Washer - Flat	5-3, 3-26
182098	Setscrew	4-4
183153	Heater	5-4
183322	Screw	3-4, 3-5, 3-9, 3-11, 3-12, 3-16, 3-18, 3-19, 3-23, 3-25, 3-26
183498	Washer - Flat	4-1, 6-4, 7-6
183624	Screw	3-7, 3-9, 3-14, 3-16, 3-21, 3-23
183882	Adapter	6-3, 6-9
187213	Washer - Lock	5-4, 7-7
187235	Screw	2-1
187283	Washer - Lock	3-4, 3-5
190481	Bearing - Ball	4-1
190596	Screw	3-9, 3-16, 3-23
191097	Screw - Jack	7-5
191098	Washer - Lock	7-7
192019	Bearing	4-2
202888	Retainer	2-2
209234	Washer - Nylon	7-5
227322	Battery	7-3
240060	Bearing	3-11, 3-12
240061	Bearing	3-11, 3-12
240065	Spacer	3-11
240066	Roller Assembly	3-1, 3-11, 3-12
240067	Roller Assembly	3-1, 3-11, 3-12
240627	Strip - Terminal, TB1	7-1
240628	Tubing - Formed	6-1
240680	Developer Rack Assembly	3-7
240682	Wash Rack Assembly	3-21
240683	Detector Crossover Assembly	3-4, 3-5
240684	Developer/Fixer Crossover Assembly	3-11, 3-12
240685	Fixer/Wash Crossover Assembly	3-18, 3-19
240686	Squeegee Assembly	3-25, 3-26
240864	Guard - Splash	8-2
240888	Valve - Replenishment, check	6-1, 6-2, 6-7
246612	Bar - Rack support	4-2, 4-4
246725	Header - Spray	3-18, 3-19
246746	Bracket	6-5

Part Number	Description	Figure Number
246800	Clamp - Hose, narrow band size 2, range .219 - .625m, width .312.....	4-3, 6-1
246801	Clamp - Hose, narrow band size 3	6-3, 6-9
246807	Clamp - Band	5-1
246808	Clamp - Hose, wide band size 10, range .500 - 1.125 width .562	6-1, 6-2, 6-3, 6-4, 6-9
246879	Sideplate - Detector crossover.....	3-4, 3-5
246890	Tubing - Formed.....	6-2
246915	Roller - Pressure, drive	3-1, 3-21
246916	Roller - Pressure, driven	3-1, 3-21
261279	Roller - A	3-1, 3-9, 3-16, 3-23
261391	Canister - Developer filter	6-1, 6-5
261413	Earth Quake Bracket Kit, includes:	8-1
261619	Screw - Panel.....	2-2
261892	Roller - Z.....	3-15
264405	Holder - Fuse.....	7-1
264407	Fuse - F3.....	7-1
264983	Blower	5-5
273691	Fuse - F2, 2.5 Amp, slow-blow	7-4
282902	Tee - ½ PT x ½ Barb x ½ Barb	6-3, 6-9
286900	Sideplate - Crossover.....	3-11, 3-12, 3-18, 3-19
286904	Sideplate - Developer, non-drive	3-7, 3-9
286907	Sideplate - Developer, drive.....	3-7, 3-9
286910	Sideplate - Wash, non-drive.....	3-21, 3-23
286912	Sideplate - Wash, drive.....	3-21, 3-23
286914	Sideplate - Fixer, non-drive.....	3-14, 3-16
286917	Sideplate - Fixer, drive	3-14, 3-16
286922	Sideplate - Squeegee.....	3-25, 3-26
286949	Dryer Transport Roller Assembly.....	3-1, 5-2
288235	Strip - Tap.....	7-7
333432	Tubing- Formed.....	6-3
333439	Tubing - Flared.....	6-1, 6-2
333465	Tubing - Formed, 13.0 in.	6-2
333966	Tubing - Formed.....	6-1
335534	Fixer Rack Assembly.....	3-14
335977	Developer Turnaround Assembly.....	3-9
379381	Fuse - F1, ¼ Amp, slow-blow	7-4
379569	Receptacle - J18	7-4
418700	Housing - Inner.....	6-6
418701	Inner Housing and Impeller Assembly	6-6
422206	Receptacles - J9, J12, J13	7-4
429715	Clamp - Hose, narrow band size 2, range .359 - .391, width .220.....	6-1, 6-2
452044	Key.....	3-4, 3-11, 3-18, 3-25
452946	Screw.....	6-6
454027	Film Guide Assembly	2-4
454285	Sprocket.....	3-7, 3-14, 3-21
454354	Key.....	3-7, 3-14, 3-21
456162	Shaft	3-1, 5-2
458162	Bracket - Guide Shoe.....	3-25, 3-26

Part Number	Description	Figure Number
458164	Shaft - Drive	3-18, 3-19
458170	Rod - Tie.....	3-4, 3-5, 3-11, 3-12, 3-18, 3-19, 3-25, 3-26
458174	Spacer - Sleeve.....	3-4, 3-18, 3-25
458175	Shaft	3-4, 3-5, 3-18, 3-19, 3-25, 3-26
458187	Sprocket.....	4-1
458205	Spacer	3-7, 3-14, 3-21
458207	Shaft	3-7, 3-9, 3-14, 3-16, 3-23
458208	Washer	3-26
458219	Rod - Tie.....	3-7, 3-14
458228	Shoe - Guide	3-9, 3-16, 3-23
458235	Shaft - Drive	3-4, 3-5, 3-25, 3-26
458236	Spacer	3-5, 3-26
458240	Chain	3-21
458382	Gear.....	3-26
458384	Gear - Idler	3-1, 5-3, 3-11, 3-21
458385	Gear - 29-Tooth.....	3-26
458386	Screw - Shoulder.....	3-26
458387	Spacer	3-26
458389	Bearing	3-25, 3-26
458390	Shaft	3-25, 3-26
458391	Shaft	3-25, 3-26
458393	Shaft	3-25, 3-26
458394	Rod - Tie.....	3-4, 3-5, 3-25, 3-26
458423	Roller Assembly - J	3-1, 3-25, 3-26
458478	Handle	2-2
458901	Pulley.....	3-1, 5-2, 5-3
458949	Roller Assembly - L & N	3-1, 3-25, 3-26
458952	Setscrew	5-3
458953	Shoe - Guide	3-4, 3-5, 3-11, 3-12
458954	Shoe - Guide	3-11, 3-12, 3-18, 3-19, 3-25, 3-26
459229	Screw - Leveling.....	8-1
459263	Chain	3-7, 3-9, 3-23
459343	Washer - Flat.....	3-9, 4-1, 3-16, 3-21, 3-23

Part Number	Description	Figure Number
459344	Spring	3-11, 3-12, 3-25, 3-26
459347	Collar	3-7, 3-14
459355	Spacer	3-7, 3-14
459378	Tie Rod Assembly	3-7, 3-14, 3-21
459379	Roller	3-1, 5-2
459432	Tray - Drip	8-2
459548	Plate - Floor	8-1
459600	Tubing	6-2
459943	Washer - ID	3-7
459944	Washer - ID	3-14
459945	Washer - ID	3-21
459946	Washer - ID	3-11
459947	Washer - ID	3-18
462139	Washer	3-25
462688	Chain	3-14, 3-16
463004	Spacer	3-7, 3-9, 3-14, 3-16, 3-23
463100	Washer - Thrust	3-7, 3-9, 3-14, 3-16, 3-21, 3-23
463363	O-Ring	6-6
464101	Tubing - 13.0 in.	6-2
466556	Gear	3-7, 3-14
466641	Support	4-4
467015	Roller - F	3-1, 3-7, 3-14
467016	Roller Assembly - K	3-1, 3-25, 3-26
467017	Roller Assembly	3-1, 5-3, 3-18, 3-19, 3-25, 3-26
467563	Idler	3-2
467564	Gear	3-1, 3-2, 3-8, 3-15, 3-22
467843	Spring	3-7, 3-14
468535	Adapter - Exhaust	2-3
470085	Roller Assembly	3-1, 3-18, 3-19, 3-25, 3-26
470086	Roller - G	3-1, 3-7, 3-14
470153	Handle - Top cover	2-1
470203	Bearing Assembly	5-5
471397	Tube - Air	3-1
472192	Support	4-2
472261	Strainer Assembly, complete	8-2
472265	Plate - Locking	3-9, 3-16, 3-23
472268	Clip	3-11, 3-12, 3-18, 3-19
472315	Shaft	4-1
472446	Shaft	4-2

Part Number	Description	Figure Number
472592	Bearing - Rocker	3-4, 3-5
472605	Housing - Outer, left.....	6-6
472606	Housing - Outer, right.....	6-6
472755	Nut - Long.....	3-5, 3-12, 3-19, 3-26
472756	Nut - Tie Rod, nylon.....	3-4, 3-11, 3-18, 3-25
472989	Collar	4-2
473146	Roller - B	3-1, 3-16, 3-23
473220	Bushing.....	3-7, 3-14
473221	Plate - Keeper	3-7, 3-14
473538	Spacer	3-7, 3-14, 3-21
473539	Spacer	3-7, 3-14
473926	Magnet - Drive.....	6-6
474100	Spacer	3-21
474180	Support	3-4, 3-5
474362	Impeller	6-6
474442	Belt.....	5-5
474472	Guide Bar Assembly.....	3-22
474596	Bracket - Guide shoe	3-4, 3-5, 3-9, 3-11, 3-12, 3-16, 3-18, 3-19, 3-23, 3-25, 3-26
474599	Roller - Rewet.....	3-1, 3-7, 3-14
474645	Spring	3-9, 3-16, 3-23
474692	Pulley - Blower	5-5
474693	Pulley	5-5
474777	Stud	3-8, 3-15, 3-22
475453	Roller - T.....	3-1, 3-8
475492	Cap	6-1, 6-2, 6-3, 6-9
475499	Fitting Tee ½ x ½ x ¼	6-2
477000	Sideplate - Non-drive.....	3-9, 3-16, 3-23
477001	Sideplate - Drive.....	3-9, 3-16, 3-23
477093	Spacer	3-21
477506	Carrier - Fuse	7-4
477871	Capacitor	6-6
478560	Switch - Replenishment, check.....	6-7
479820	Spring	3-21
479821	Cylinder - Graduated	6-1, 6-7, 8-2
489693	Roller	3-1, 3-2, 3-8, 3-15, 3-22
489695	Roller - H	3-1, 3-8, 3-15
489697	Roller - E	3-1, 3-8, 3-15, 3-22

Part Number	Description	Figure Number
489699	Roller - C	3-1, 3-8, 3-15, 3-22
489997	Standoff - Pivot.....	3-4, 3-5
490096	Screw	3-9, 3-16, 3-23
490108	Roller - Detector, drive	3-1, 3-4, 3-5
490109	Roller - Detector, driven	3-1, 3-4, 3-5
492104	Roller - D	3-1, 3-8, 3-15, 3-22
493400	Relief - Strain.....	5-4
493505	Washer	6-6
498607	Holder - Fuse.....	7-4
499753	Retainer	2-2
520388	O-Ring	6-8
520390	Elbow	6-8
520391	Nut	6-8
522359	Label - Developer	6-4, 6-7
522368	Guard - Pump.....	2-6
528291	Washer	7-7
529615	Label - Fixer	6-4, 6-7
532008	Bellows	6-8
532033	Adapter	6-4
532095	Exchanger - Heat	6-3, 6-10
532377	Washer	6-10
532378	Seal.....	6-3, 6-10
532379	Washer	6-3
534764	Elbow - ½ Pt x ½ Barb.....	6-1, 6-2, 6-9
535004	Washer - Lock	4-1, 4-2, 6-4
535265	Strip - Terminal, TB5.....	7-2
535561	Screw.....	7-7
535638	Valve Body	6-8
535639	O-Ring	6-8
536884	Roller - B	3-1, 3-9
539198	Idler.....	3-1, 3-8, 3-15, 3-22
541262	Screw.....	5-6
541891	Plug.....	6-4
544081	Pin.....	3-1, 3-11, 3-21
544194	Screw.....	3-4, 3-5
550774	Gear.....	3-7, 3-14, 3-21
550781	Gear - Drive, crossover.....	3-4, 3-11, 3-18, 3-25
558648	Receptacles - J14, J15, J10	7-4
559787	Shaft	3-7, 3-14
562201	Screw - Countersink.....	4-1
562485	O-Ring	6-5
562553	Filter Cap Assembly	6-1, 6-5
562602	Plug - Gland sealing.....	6-3, 6-10
562609	Spring	5-2
562670	Block	5-2

Part Number	Description	Figure Number
562765	Shoe - Guide	3-9, 3-16, 3-23
562790	Cartridge - Filter	6-1, 6-5
575821	Screw	3-4, 3-5
575822	Washer	3-4, 3-5
581094	Washer - Garden hose	6-3
583127	Valve - Chemical drain	6-1, 6-2, 6-9
587227	Nut	4-3
594431	Adapter - Garden hose	6-3
594466	Connector - Interface	7-5
594534	Washer - Metal	4-3
594838	Cup - Displacement	6-8
594839	Nut - Coupling	6-8
607748	Thermowell	6-1, 6-2, 6-4
607793	Locator	6-4
607833	Sprocket	3-1, 3-2, 3-8, 3-15, 3-22
609817	Valve Assembly	6-8
618502	Diode Assembly	6-4
622026	Bracket - Heater	5-4
650663	Gear	4-1
650701	Bearing	3-21
650702	Bearing	3-7, 3-9, 3-14, 3-16, 3-21, 3-23
650703	Bearing	3-4, 3-5, 3-18, 3-19
650705	Bearing	3-25, 3-26
650707	Bearing	3-4, 3-5, 3-18, 3-19
650711	Bearing	3-7, 3-9, 3-14, 3-16, 3-23
650876	Actuator - Magnetic	3-4, 3-5
650938	Gasket - Light tight, 10 ft. roll	8-2
655290	Solid State Relay	7-2
659590	Thermostat - Overtemperature	5-4
744714	Plug - Adapter	8-2
748245	Clamp	6-1, 6-2, 6-9
748249	Elbow - ½ x ¾ in.	6-1, 6-2, 6-9
748427	Nipple - ½ x 2 ½ in.	6-1, 6-2, 6-9
748449	Hose	5-1
748585	Tee - ½ x ¾ x ¾ in.	6-1, 6-2, 6-9
748699	Turnaround Assembly	3-16, 3-23
748955	Gear - Worm, left-hand	4-1, 4-2
748956	Gear - Right, hand worm	4-2
760476	Tubing	6-1
779051	Washer - Flat	5-3
779232	Tube - Air	5-2
779234	Panel - Control	7-5
779241	Solenoid Valve - Inlet	6-3
779243	Solenoid - Cooling/wash dump	6-3, 6-4
779273	Breaker - Circuit, 15 A, CB3	7-1

Part Number	Description	Figure Number
779325	Gearbox	4-3
779336	Tray - Film exit	2-1
779400	Strip - Terminal.....	7-2
779409	Transformer - T2	7-2
779718	Panel.....	6-9
779727	Pulley.....	5-6
779728	Bushing.....	4-1
779729	Sprocket - Drive.....	4-3
779730	Cover - Heat Exchanger	6-10
779749	Sleeve.....	5-6
781230	Filter - RFI	7-2
781405	Receptacle - 110 Volt.....	7-5
850897	Washer - Lock	4-1, 5-3
852073	Locknut	5-4
852520	Screw	4-1, 4-2
852522	Screw.....	2-3, 4-1
852558	Setscrew	4-1, 4-3
852559	Setscrew	5-5
852611	Washer	2-3, 2-4, 2-5, 3-4, 3-5, 3-7, 5-1, 5-2, 5-4, 6-9, 3-11, 3-12, 3-14, 3-18, 3-19, 3-21, 3-25, 3-26
852613	Washer	5-5
852615	Washer	5-5
852616	Washer	2-1
852617	Washer - Lock	5-5
852630	Washer	4-1, 5-6
852656	Washer - Lock	5-5
852682	Screw.....	2-5, 3-4, 3-5, 3-7, 3-9, 5-1, 5-2, 5-4, 6-5, 6-9, 7-5, 7-6, 3-11, 3-12, 3-14, 3-16, 3-18, 3-19, 3-21, 3-22, 3-23, 3-25, 3-26
852805	Screw.....	4-4
852807	Screw.....	3-4, 3-5, 3-7, 3-14, 3-21, 3-25, 3-26
852808	Screw.....	2-1, 5-3
852809	Screw	5-3
852810	Screw	5-3
852831	Washer	2-6
852835	Screw.....	2-6, 7-5, 7-7

Part Number	Description	Figure Number
852845	Setscrew	4-2
852847	Setscrew	3-1
852857	Setscrew	5-2
852871	Screw	6-4
852873	Washer	2-1, 4-3, 6-6
852888	Screw	2-4
852889	Setscrew	3-7, 3-14
852895	Screw	6-6
852941	Screw	3-4, 3-5, 3-9, 4-1, 3-11, 3-12, 3-16, 3-18, 3-19, 3-23, 3-25, 3-26
852946	Screw	2-3
852961	Washer - Lock	2-1, 4-3
852971	Screw	5-4
852972	Screw	2-2, 4-1
853000	Pin	4-2
853006	Screw	5-5
853011	Washer	2-4
853051	Ring - Retaining	4-1
853063	Fitting - Barbed	6-3, 6-9
853069	Pin	4-1
853086	Washer - Lock	6-6
853087	Washer - Lock	3-4, 3-5, 3-7, 3-11, 3-12, 3-14, 3-18, 3-19, 3-21, 3-25, 3-26
853096	Washer - Lock	3-4, 3-5
853100	Washer - Lock	2-3, 2-4, 2-5, 5-1, 5-2, 5-4, 6-5, 6-9, 7-6
853186	Screw	4-1
869623	Label - Modification	6-7
911150	Chain	4-1, 4-3
911151	Coupling - Drain	6-3, 6-9
911400	Connector - P2	7-4
911404	Receptacles - J4, J5, J6,J7, J8, J17, J100	7-4
911406	Receptacle - J3	7-4
911412	Controller - DC Motor	7-2
911419	Breaker - Circuit, 10 A, CB2, CB4	7-1
911420	Breaker - Circuit, 35 amp	7-5
911424	Filter - FL1, FL2, FL3	7-1
911425	5600 Circuit Board Assembly	7-7
911428	Blower - Exhaust	5-1
911438	Strip - Terminal	5-4
911480	Tubing - Formed, flared	6-3
911483	Tubing	6-1
911485	Tubing - Formed, flared	6-2
911486	Tubing - Flared, 53 in., high pressure	6-3

Part Number	Description	Figure Number
911487	Tubing - Formed.....	6-3
911491	Recirculation Pump Assembly.....	6-6
911640	Shelf - Feed, complete.....	2-4
911713	Bracket - Hinge.....	2-1
911714	Plate - Hinge, right-hand.....	2-1
911715	Plate - Hinge, left-hand.....	2-1
911716	Pin - Hinge, right-hand.....	2-1
911717	Hinge - Nut, plate.....	2-1
914234	Strip - Terminal, TB2.....	7-1
914235	Strip - Marker.....	7-1
914308	Panel - Access.....	2-3
914310	Guard.....	5-5
914313	Cover - Dryer blower motor.....	2-6
914491	Recirculation Pump Assembly.....	6-1, 6-2
914493	Counter.....	7-2
914498	Tubing - Formed.....	6-1
914507	Bearing.....	3-25, 3-26
914518	Screw.....	4-3
914544	Bracket - Switch, left.....	7-7
914545	Bracket - Switch, right.....	7-7
914599	Reed Switch Assembly.....	7-7
914784	Bezel - Filter.....	2-5
914803	Heater - Fixer, 1200 watts.....	6-4
914804	Heater - Developer, 1000 watts.....	6-4
914807	Spring.....	6-8
914808	E-Ring.....	6-8
914809	Connecting Rod Assembly.....	6-8
914811	Crank.....	6-8
914812	Guide.....	6-8
918097	200 Circuit Board Assembly.....	7-5
918204	Relay - K8.....	7-2
918211	Filter - FL4.....	7-1
918801	Transformer - T1.....	7-1
918804	Network - Arc suppression.....	7-2
918877	Bearing Block Assembly - Right.....	5-3
918884	Panel - Side, aluminum, complete.....	2-2
918886	Cover - Top.....	2-1
918889	Orifice, .220 I D.....	6-1, 6-2
943202	Roller - Idler.....	4-1
943204	Bezel - Overlay.....	7-5
943205	Tubing - Formed.....	6-1
943208	Spacer.....	6-5
943211	Replenishment Pump Assembly, complete.....	6-1, 6-2, 6-8
943525	Guard - Splash, end.....	2-5
943700	Insert - Quick disconnect.....	4-3, 3-18
943701	Coupling - Quick disconnect, panel mount.....	4-3, 6-3
943707	Retainer.....	2-1
943716	Panel - Dryer.....	2-1
943717	Panel - Access, receive end.....	2-1
955703	Motor - DC Drive.....	4-3
955745	Quad Power Supply.....	7-2
955747	Cable - Adapter.....	8-2
963435	Bearing.....	4-1

Part Number	Description	Figure Number
963610	Thermistor.....	6-4
963611	Motor - Blower	5-5
963622	Bearing Block Assembly - Left.....	5-3
963624	Cover	7-7
963806	Shoe	5-3
963808	Shaft	5-3
963809	Tubing - Formed, flared	6-3
963962	Level Sensing Assembly	4-4
963965	Roller - Idler	4-1
963969	Pivot Assembly	4-1
963974	Shaft - Turnaround, drive	5-3
968067	Tank.....	4-4
968073	Block - Shoe, mounting.....	5-3
968175	500 Circuit Board Assembly.....	7-2
968179	Panel - Ribbed.....	5-2
968180	Roller - Turnaround	3-1, 5-3
968186	Cover - Heater.....	5-4
968195	Bracket - Motor, mount	4-3
968197	Idler - Shaft.....	4-1
968199	Stud - Special	4-1
968433	Belt.....	4-1, 5-6
968434	Roller - Drive, crowned	4-1
968442	Eprom - U5612.....	7-7
968443	Pin - Hinge, left-hand	2-1
968444	Spacer	5-3
968445	Spring - Belt tensioner	4-1
968446	Spacer - Spring, belt tensioner	4-1
969175	500 Circuit Board Assembly, packed, does not include U17 - U20.....	7-3
981007	Guard - Splash, drive side	2-5
981008	Panel - Access transformer.....	2-3
981010	U17, U18, U19.....	7-3
981011	U17, U18, U19.....	7-3
981012	Spring - Hinge, drive side	2-1
981013	Spring - Hinged, non-drive side	2-1
981018	Panel - Side, plastic, complete	2-1
981099	U20	7-3
981425	350 Circuit Board Display Assembly.....	7-6
981751	Screw - Panel.....	2-1

BLANK PAGE

SECTION 10

Alphabetical Index

Part Number	Description	Figure Number
918097	200 Circuit Board Assembly.....	7-5
981425	350 Circuit Board Display Assembly.....	7-6
968175	500 Circuit Board Assembly.....	7-2
969175	500 Circuit Board Assembly, packed, does not include U17 - U20.....	7-3
911425	5600 Circuit Board Assembly.....	7-7
650876	Actuator - Magnetic.....	3-4, 3-5
183882	Adapter.....	6-3, 6-9
532033	Adapter.....	6-4
468535	Adapter - Exhaust.....	2-3
594431	Adapter - Garden hose.....	6-3
246612	Bar - Rack support.....	4-2, 4-4
227322	Battery.....	7-3
192019	Bearing.....	4-2
240060	Bearing.....	3-11, 3-12
240061	Bearing.....	3-11, 3-12
458389	Bearing.....	3-25, 3-26
650701	Bearing.....	3-21
650702	Bearing.....	3-7, 3-9, 3-14, 3-16, 3-21, 3-23
650703	Bearing.....	3-4, 3-5, 3-18, 3-19
650705	Bearing.....	3-25, 3-26
650707	Bearing.....	3-4, 3-5, 3-18, 3-19
650711	Bearing.....	3-7, 3-9, 3-14, 3-16, 3-23
914507	Bearing.....	3-25, 3-26
963435	Bearing.....	4-1
190481	Bearing - Ball.....	4-1
472592	Bearing - Rocker.....	3-4, 3-5
470203	Bearing Assembly.....	5-5
963622	Bearing Block Assembly - Left.....	5-3
918877	Bearing Block Assembly - Right.....	5-3
532008	Bellows.....	6-8
474442	Belt.....	5-5
968433	Belt.....	4-1, 5-6
914784	Bezel - Filter.....	2-5
943204	Bezel - Overlay.....	7-5
562670	Block.....	5-2
968073	Block - Shoe, mounting.....	5-3
264983	Blower.....	5-5
911428	Blower - Exhaust.....	5-1
246746	Bracket.....	6-5
458162	Bracket - Guide Shoe.....	3-25, 3-26

Part Number	Description	Figure Number
474596	Bracket - Guide shoe	3-4, 3-5, 3-9, 3-11, 3-12, 3-16, 3-18, 3-19, 3-23, 3-25, 3-26
622026	Bracket - Heater	5-4
911713	Bracket - Hinge.....	2-1
968195	Bracket - Motor, mount	4-3
914544	Bracket - Switch, left	7-7
914545	Bracket - Switch, right.....	7-7
911419	Breaker - Circuit, 10 A, CB2, CB4.....	7-1
779273	Breaker - Circuit, 15 A, CB3	7-1
911420	Breaker - Circuit, 35 amp.....	7-5
473220	Bushing.....	3-7, 3-14
779728	Bushing.....	4-1
955747	Cable - Adapter	8-2
261391	Canister - Developer filter	6-1, 6-5
475492	Cap	6-1, 6-2, 6-3, 6-9
477871	Capacitor	6-6
477506	Carrier - Fuse	7-4
562790	Cartridge - Filter	6-1, 6-5
458240	Chain	3-21
459263	Chain	3-7, 3-9, 3-23
462688	Chain	3-14, 3-16
911150	Chain	4-1, 4-3
748245	Clamp	6-1, 6-2, 6-9
246807	Clamp - Band	5-1
246800	Clamp - Hose, narrow band size 2, range .219 - .625m, width .312.....	4-3, 6-1
429715	Clamp - Hose, narrow band size 2, range .359 - .391, width .220.....	6-1, 6-2
246801	Clamp - Hose, narrow band size 3	6-3, 6-9
246808	Clamp - Hose, wide band size 10, range .500 - 1.125 width .562.....	6-1, 6-2, 6-3, 6-4, 6-9
472268	Clip.....	3-11, 3-12, 3-18, 3-19
459347	Collar	3-7, 3-14
472989	Collar	4-2
914809	Connecting Rod Assembly	6-8
594466	Connector - Interface.....	7-5
911400	Connector - P2.....	7-4
911412	Controller - DC Motor	7-2
914493	Counter	7-2
911151	Coupling - Drain	6-3, 6-9
943701	Coupling - Quick disconnect, panel mount.....	4-3, 6-3
963624	Cover	7-7
914313	Cover - Dryer blower motor	2-6
779730	Cover - Heat Exchanger	6-10
968186	Cover - Heater.....	5-4
918886	Cover - Top	2-1
914811	Crank	6-8
594838	Cup - Displacement.....	6-8
479821	Cylinder - Graduated.....	6-1, 6-7, 8-2
240683	Detector Crossover Assembly.....	3-4, 3-5

Part Number	Description	Figure Number
240680	Developer Rack Assembly	3-7
335977	Developer Turnaround Assembly.....	3-9
240684	Developer/Fixer Crossover Assembly	3-11, 3-12
618502	Diode Assembly.....	6-4
286949	Dryer Transport Roller Assembly.....	3-1, 5-2
136224	E-Ring.....	2-1
914808	E-Ring.....	6-8
261413	Earth Quake Bracket Kit, includes:	8-1
520390	Elbow	6-8
534764	Elbow - ½ Pt x ½ Barb.....	6-1, 6-2, 6-9
748249	Elbow - ½ x ¾ in.	6-1, 6-2, 6-9
968442	Eprom - U5612.....	7-7
532095	Exchanger - Heat	6-3, 6-10
454027	Film Guide Assembly	2-4
911424	Filter - FL1, FL2, FL3	7-1
918211	Filter - FL4.....	7-1
781230	Filter - RFI	7-2
562553	Filter Cap Assembly	6-1, 6-5
853063	Fitting - Barbed.....	6-3, 6-9
475499	Fitting Tee ½ x ½ x ¼	6-2
335534	Fixer Rack Assembly.....	3-14
240685	Fixer/Wash Crossover Assembly	3-18, 3-19
379381	Fuse - F1, ¼ Amp, slow-blow	7-4
273691	Fuse - F2, 2.5 Amp, slow-blow	7-4
264407	Fuse - F3.....	7-1
650938	Gasket - Light tight, 10 ft. roll	8-2
458382	Gear.....	3-26
466556	Gear.....	3-7, 3-14
467564	Gear.....	3-1, 3-2, 3-8, 3-15, 3-22
550774	Gear.....	3-7, 3-14, 3-21
650663	Gear.....	4-1
458385	Gear - 29-Tooth.....	3-26
550781	Gear - Drive, crossover.....	3-4, 3-11, 3-18, 3-25
458384	Gear - Idler	3-1, 5-3, 3-11, 3-21
748956	Gear - Right, hand worm	4-2
748955	Gear - Worm, left-hand	4-1, 4-2
779325	Gearbox.....	4-3
914310	Guard.....	5-5
522368	Guard - Pump.....	2-6
240864	Guard - Splash	8-2
981007	Guard - Splash, drive side	2-5
943525	Guard - Splash, end.....	2-5
914812	Guide	6-8
474472	Guide Bar Assembly.....	3-22
458478	Handle	2-2
470153	Handle - Top cover	2-1
246725	Header - Spray.....	3-18, 3-19
183153	Heater	5-4
914804	Heater - Developer, 1000 watts.....	6-4

Part Number	Description	Figure Number
914803	Heater - Fixer, 1200 watts	6-4
911717	Hinge - Nut, plate	2-1
264405	Holder - Fuse.....	7-1
498607	Holder - Fuse.....	7-4
748449	Hose	5-1
418700	Housing - Inner.....	6-6
472605	Housing - Outer, left.....	6-6
472606	Housing - Outer, right.....	6-6
467563	Idler	3-2
539198	Idler	3-1, 3-8, 3-15, 3-22
968197	Idler - Shaft.....	4-1
474362	Impeller	6-6
418701	Inner Housing and Impeller Assembly	6-6
943700	Insert - Quick disconnect	4-3, 3-18
452044	Key.....	3-4, 3-11, 3-18, 3-25
454354	Key.....	3-7, 3-14, 3-21
522359	Label - Developer	6-4, 6-7
529615	Label - Fixer	6-4, 6-7
869623	Label - Modification	6-7
963962	Level Sensing Assembly	4-4
607793	Locator.....	6-4
852073	Locknut	5-4
473926	Magnet - Drive.....	6-6
963611	Motor - Blower	5-5
955703	Motor - DC Drive	4-3
918804	Network - Arc suppression.....	7-2
748427	Nipple - ½ x 2 ½ in.....	6-1, 6-2, 6-9
166331	Nut	5-5
520391	Nut	6-8
587227	Nut	4-3
594839	Nut - Coupling	6-8
472755	Nut - Long.....	3-5, 3-12, 3-19, 3-26
472756	Nut - Tie Rod, nylon.....	3-4, 3-11, 3-18, 3-25
144097	Nut - Wing	2-4, 6-6
463363	O-Ring	6-6
520388	O-Ring	6-8
535639	O-Ring	6-8
562485	O-Ring	6-5
918889	Orifice, .220 I D	6-1, 6-2
779718	Panel.....	6-9
914308	Panel - Access	2-3
981008	Panel - Access transformer.....	2-3
943717	Panel - Access, receive end	2-1
779234	Panel - Control	7-5
943716	Panel - Dryer	2-1
968179	Panel - Ribbed.....	5-2
918884	Panel - Side, aluminum, complete	2-2
981018	Panel - Side, plastic, complete	2-1

Part Number	Description	Figure Number
544081	Pin.....	3-1, 3-11, 3-21
853000	Pin.....	4-2
853069	Pin.....	4-1
968443	Pin - Hinge, left-hand	2-1
911716	Pin - Hinge, right-hand	2-1
963969	Pivot Assembly.....	4-1
459548	Plate - Floor.....	8-1
911715	Plate - Hinge, left-hand	2-1
911714	Plate - Hinge, right-hand.....	2-1
473221	Plate - Keeper	3-7, 3-14
472265	Plate - Locking.....	3-9, 3-16, 3-23
541891	Plug.....	6-4
744714	Plug - Adapter	8-2
562602	Plug - Gland sealing.....	6-3, 6-10
458901	Pulley	3-1, 5-2, 5-3
474693	Pulley	5-5
779727	Pulley.....	5-6
474692	Pulley - Blower	5-5
955745	Quad Power Supply	7-2
781405	Receptacle - 110 Volt.....	7-5
379569	Receptacle - J18	7-4
911406	Receptacle - J3	7-4
558648	Receptacles - J14, J15, J10	7-4
911404	Receptacles - J4, J5, J6,J7, J8, J17, J100	7-4
422206	Receptacles - J9, J12, J13	7-4
911491	Recirculation Pump Assembly.....	6-6
914491	Recirculation Pump Assembly.....	6-1, 6-2
914599	Reed Switch Assembly.....	7-7
918204	Relay - K8.....	7-2
493400	Relief - Strain.....	5-4
943211	Replenishment Pump Assembly, complete	6-1, 6-2, 6-8
202888	Retainer	2-2
499753	Retainer	2-2
943707	Retainer	2-1
853051	Ring - Retaining.....	4-1
458170	Rod - Tie.....	3-4, 3-5, 3-11, 3-12, 3-18, 3-19, 3-25, 3-26
458219	Rod - Tie.....	3-7, 3-14
458394	Rod - Tie.....	3-4, 3-5, 3-25, 3-26
459379	Roller	3-1, 5-2
489693	Roller	3-1, 3-2, 3-8, 3-15, 3-22
261279	Roller - A	3-1, 3-9, 3-16, 3-23
473146	Roller - B	3-1, 3-16, 3-23
536884	Roller - B	3-1, 3-9

Part Number	Description	Figure Number
489699	Roller - C	3-1, 3-8, 3-15, 3-22
492104	Roller - D	3-1, 3-8, 3-15, 3-22
490108	Roller - Detector, drive	3-1, 3-4, 3-5
490109	Roller - Detector, driven	3-1, 3-4, 3-5
968434	Roller - Drive, crowned	4-1
489697	Roller - E	3-1, 3-8, 3-15, 3-22
467015	Roller - F.....	3-1, 3-7, 3-14
470086	Roller - G.....	3-1, 3-7, 3-14
489695	Roller - H.....	3-1, 3-8, 3-15
943202	Roller - Idler.....	4-1
963965	Roller - Idler.....	4-1
246915	Roller - Pressure, drive	3-1, 3-21
246916	Roller - Pressure, driven	3-1, 3-21
474599	Roller - Rewet.....	3-1, 3-7, 3-14
475453	Roller - T.....	3-1, 3-8
968180	Roller - Turnaround	3-1, 5-3
261892	Roller - Z.....	3-15
240066	Roller Assembly.....	3-1, 3-11, 3-12
240067	Roller Assembly.....	3-1, 3-11, 3-12
467017	Roller Assembly.....	3-1, 5-3, 3-18, 3-19, 3-25, 3-26
470085	Roller Assembly.....	3-1, 3-18, 3-19, 3-25, 3-26
458423	Roller Assembly - J	3-1, 3-25, 3-26
467016	Roller Assembly - K	3-1, 3-25, 3-26
458949	Roller Assembly - L & N	3-1, 3-25, 3-26
171950	Screw.....	4-3
183322	Screw.....	3-4, 3-5, 3-9, 3-11, 3-12, 3-16, 3-18, 3-19, 3-23, 3-25, 3-26
183624	Screw.....	3-7, 3-9, 3-14, 3-16, 3-21, 3-23
187235	Screw.....	2-1
190596	Screw.....	3-9, 3-16, 3-23
452946	Screw.....	6-6
490096	Screw.....	3-9, 3-16, 3-23
535561	Screw.....	7-7
541262	Screw.....	5-6

Part Number	Description	Figure Number
544194	Screw.....	3-4, 3-5
575821	Screw.....	3-4, 3-5
852520	Screw.....	4-1, 4-2
852522	Screw.....	2-3, 4-1
852682	Screw.....	2-5, 3-4, 3-5, 3-7, 3-9, 5-1, 5-2, 5-4, 6-5, 6-9, 7-5, 7-6, 3-11, 3-12, 3-14, 3-16, 3-18, 3-19, 3-21, 3-22, 3-23, 3-25, 3-26
852805	Screw.....	4-4
852807	Screw.....	3-4, 3-5, 3-7, 3-14, 3-21, 3-25, 3-26
852808	Screw.....	2-1, 5-3
852809	Screw.....	5-3
852810	Screw.....	5-3
852835	Screw.....	2-6, 7-5, 7-7
852871	Screw.....	6-4
852888	Screw.....	2-4
852895	Screw.....	6-6
852941	Screw.....	3-4, 3-5, 3-9, 4-1, 3-11, 3-12, 3-16, 3-18, 3-19, 3-23, 3-25, 3-26
852946	Screw.....	2-3
852971	Screw.....	5-4
852972	Screw.....	2-2, 4-1
853006	Screw.....	5-5
853186	Screw.....	4-1
914518	Screw.....	4-3
562201	Screw - Countersink.....	4-1
191097	Screw - Jack.....	7-5
459229	Screw - Leveling.....	8-1
261619	Screw - Panel.....	2-2
981751	Screw - Panel.....	2-1
458386	Screw - Shoulder.....	3-26
532378	Seal.....	6-3, 6-10
182098	Setscrew.....	4-4
458952	Setscrew.....	5-3
852558	Setscrew.....	4-1, 4-3
852559	Setscrew.....	5-5
852845	Setscrew.....	4-2
852847	Setscrew.....	3-1
852857	Setscrew.....	5-2
852889	Setscrew.....	3-7, 3-14

Part Number	Description	Figure Number
456162	Shaft	3-1, 5-2
458175	Shaft	3-4, 3-5, 3-18, 3-19, 3-25, 3-26
458207	Shaft	3-7, 3-9, 3-14, 3-16, 3-23
458390	Shaft	3-25, 3-26
458391	Shaft	3-25, 3-26
458393	Shaft	3-25, 3-26
472315	Shaft	4-1
472446	Shaft	4-2
559787	Shaft	3-7, 3-14
963808	Shaft	5-3
458164	Shaft - Drive	3-18, 3-19
458235	Shaft - Drive	3-4, 3-5, 3-25, 3-26
963974	Shaft - Turnaround, drive	5-3
911640	Shelf - Feed, complete	2-4
963806	Shoe	5-3
458228	Shoe - Guide	3-9, 3-16, 3-23
458953	Shoe - Guide	3-4, 3-5, 3-11, 3-12
458954	Shoe - Guide	3-11, 3-12, 3-18, 3-19, 3-25, 3-26
562765	Shoe - Guide	3-9, 3-16, 3-23
286900	Sideplate - Crossover	3-11, 3-12, 3-18, 3-19
246879	Sideplate - Detector crossover	3-4, 3-5
286907	Sideplate - Developer, drive	3-7, 3-9
286904	Sideplate - Developer, non-drive	3-7, 3-9
477001	Sideplate - Drive	3-9, 3-16, 3-23
286917	Sideplate - Fixer, drive	3-14, 3-16
286914	Sideplate - Fixer, non-drive	3-14, 3-16
477000	Sideplate - Non-drive	3-9, 3-16, 3-23
286922	Sideplate - Squeegee	3-25, 3-26
286912	Sideplate - Wash, drive	3-21, 3-23
286910	Sideplate - Wash, non-drive	3-21, 3-23
779749	Sleeve	5-6
779243	Solenoid - Cooling/wash dump	6-3, 6-4
779241	Solenoid Valve - Inlet	6-3
655290	Solid State Relay	7-2
240065	Spacer	3-11
458205	Spacer	3-7, 3-14, 3-21
458236	Spacer	3-5, 3-26
458387	Spacer	3-26
459355	Spacer	3-7, 3-14

Part Number	Description	Figure Number
463004	Spacer	3-7, 3-9, 3-14, 3-16, 3-23
473538	Spacer	3-7, 3-14, 3-21
473539	Spacer	3-7, 3-14
474100	Spacer	3-21
477093	Spacer	3-21
943208	Spacer	6-5
968444	Spacer	5-3
458174	Spacer - Sleeve.....	3-4, 3-18, 3-25
968446	Spacer - Spring, belt tensioner	4-1
459344	Spring	3-11, 3-12, 3-25, 3-26
467843	Spring	3-7, 3-14
474645	Spring	3-9, 3-16, 3-23
479820	Spring	3-21
562609	Spring	5-2
914807	Spring	6-8
968445	Spring - Belt tensioner	4-1
981012	Spring - Hinge, drive side	2-1
981013	Spring - Hinged, non-drive side	2-1
454285	Sprocket.....	3-7, 3-14, 3-21
458187	Sprocket.....	4-1
607833	Sprocket.....	3-1, 3-2, 3-8, 3-15, 3-22
779729	Sprocket - Drive.....	4-3
240686	Squeegee Assembly.....	3-25, 3-26
489997	Standoff - Pivot.....	3-4, 3-5
472261	Strainer Assembly, complete.....	8-2
914235	Strip - Marker.....	7-1
288235	Strip - Tap.....	7-7
779400	Strip - Terminal.....	7-2
911438	Strip - Terminal.....	5-4
240627	Strip - Terminal, TB1	7-1
914234	Strip - Terminal, TB2.....	7-1
535265	Strip - Terminal, TB5.....	7-2
474777	Stud	3-8, 3-15, 3-22
968199	Stud - Special	4-1
466641	Support	4-4
472192	Support	4-2
474180	Support	3-4, 3-5
478560	Switch - Replenishment, check.....	6-7
968067	Tank.....	4-4
282902	Tee - ½ PT x ½ Barb x ½ Barb	6-3, 6-9
748585	Tee - ½ x ¾ x ¾ in.....	6-1, 6-2, 6-9
963610	Thermistor.....	6-4
659590	Thermostat - Overtemperature.....	5-4
607748	Thermowell	6-1, 6-2, 6-4

Part Number	Description	Figure Number
459378	Tie Rod Assembly	3-7, 3-14, 3-21
918801	Transformer - T1	7-1
779409	Transformer - T2	7-2
459432	Tray - Drip	8-2
779336	Tray - Film exit	2-1
471397	Tube - Air.....	3-1
779232	Tube - Air.....	5-2
459600	Tubing	6-2
760476	Tubing	6-1
911483	Tubing	6-1
464101	Tubing - 13.0 in.	6-2
333439	Tubing - Flared.....	6-1, 6-2
911486	Tubing - Flared, 53 in., high pressure	6-3
240628	Tubing - Formed.....	6-1
246890	Tubing - Formed.....	6-2
333966	Tubing - Formed.....	6-1
911487	Tubing - Formed.....	6-3
914498	Tubing - Formed.....	6-1
943205	Tubing - Formed.....	6-1
333465	Tubing - Formed, 13.0 in.	6-2
911480	Tubing - Formed, flared	6-3
911485	Tubing - Formed, flared	6-2
963809	Tubing - Formed, flared	6-3
333432	Tubing- Formed.....	6-3
748699	Turnaround Assembly	3-16, 3-23
981010	U17, U18, U19.....	7-3
981011	U17, U18, U19.....	7-3
981099	U20	7-3
583127	Valve - Chemical drain	6-1, 6-2, 6-9
240888	Valve - Replenishment, check	6-1, 6-2, 6-7
609817	Valve Assembly	6-8
535638	Valve Body	6-8
240682	Wash Rack Assembly	3-21
165627	Washer	3-4, 3-5, 7-7
458208	Washer	3-26
462139	Washer	3-25
493505	Washer	6-6
528291	Washer	7-7
532377	Washer	6-10
532379	Washer	6-3
575822	Washer	3-4, 3-5
852611	Washer	2-3, 2-4, 2-5, 3-4, 3-5, 3-7, 5-1, 5-2, 5-4, 6-9, 3-11, 3-12, 3-14, 3-18, 3-19, 3-21, 3-25, 3-26
852613	Washer	5-5
852615	Washer	5-5

Part Number	Description	Figure Number
852616	Washer	2-1
852630	Washer	4-1, 5-6
852831	Washer	2-6
852873	Washer	2-1, 4-3, 6-6
853011	Washer	2-4
180977	Washer - Flat.....	5-3, 3-26
183498	Washer - Flat.....	4-1, 6-4, 7-6
459343	Washer - Flat.....	3-9, 4-1, 3-16, 3-21, 3-23
779051	Washer - Flat.....	5-3
581094	Washer - Garden hose.....	6-3
459943	Washer - ID	3-7
459944	Washer - ID	3-14
459945	Washer - ID	3-21
459946	Washer - ID	3-11
459947	Washer - ID	3-18
187213	Washer - Lock	5-4, 7-7
187283	Washer - Lock	3-4, 3-5
191098	Washer - Lock	7-7
535004	Washer - Lock	4-1, 4-2, 6-4
850897	Washer - Lock	4-1, 5-3
852617	Washer - Lock	5-5
852656	Washer - Lock	5-5
852961	Washer - Lock	2-1, 4-3
853086	Washer - Lock	6-6
853087	Washer - Lock	3-4, 3-5, 3-7, 3-11, 3-12, 3-14, 3-18, 3-19, 3-21, 3-25, 3-26
853096	Washer - Lock	3-4, 3-5
853100	Washer - Lock	2-3, 2-4, 2-5, 5-1, 5-2, 5-4, 6-5, 6-9, 7-6
594534	Washer - Metal.....	4-3
209234	Washer - Nylon.....	7-5
463100	Washer - Thrust.....	3-7, 3-9, 3-14, 3-16, 3-21, 3-23

3228PL_A.txt

Kodak and X-Omat are trademarks.

Printed in USA

Customer Equipment Services Division

EASTMAN KODAK COMPANY • ROCHESTER, N.Y. 14650

